


Protecting your Equipment

John Stucka, N3JM Presented to SFDXA 6 July 2016







Have no relevant financial relationships or conflicts of interest with commercial interests related directly or indirectly to this educational activity.






- Part 1
 - Lightning the what, when, where and how
 - Lightning effects on a human


- A Part 2
 - · The challenge protect your radio equipment






- Have experience with lightning, lightning damage, lightning repair and lightning pervention
- Cannot guarantee the accuracy or completeness of any information
- Suggested lightning protection procedures may reduce total damage














































- What must be protected?
- Which protective components reduce damage?
- What methods reduce damage?
- 60 hertz grounding and radio frequency (RF) grounding
- · ? Better grounding? copper wire or copper strap
- What is complete system grounding
- Myths
- Problems

References

1 of 2


- Alliance for Telecommunications Industry Solutions
 (ATIS)
- American National Standards Institute (ANSI)
- American Radio Relay League (ARRL)
- American Society of Mechanical Engineers (ASME)
- Australian Standards (AS)
- British Standards Institution (BS)
- Cooper, MA
- Federal Aviation Agency (FAA)
- Federal Communication Commission (FCC)
- http://en.blitzortung.org/live_lightning_maps.php?map=
- Institute of Electrical and Electronics Engineers (IEEE)
- International Association of Electrical Inspectors (IAEI)
- International Electrotechnical Commission (IEC)
- Lightning, Uman, MA, 1982


References


2 of 2

- Lightning Injury Research Program (LIRP)
- Motorola Corporation
- National Electrical Manufacturers Association (NEMA)
- National Fire Protection Association (NFPA)
- National Oceanic and Atmospheric Administration (NOAA)
- PolyPhaser Corporation
- Smith Power Corporation
- Telecommunications Industry Association (TIA)
- The "Grounds" for Lightning and EMP Protection, Block,
 - RR, 1987
- Underwriters Laboratories (UL)
- United States Department of Defense (DoD)
- United States Federal Aviation Administration (FAA)
- United States National Weather Service (NWS)






























Silicon Avalnche Diode (SAD)







Protector types - AC main power


Four-layer semiconductor


"Follower" or negative resistance

Used on telephone or control lines

Silicon Controlled Rectifier

Very fast when used with SAD or MOV






Battery and charger protection









(• X•X•X•X•X•X•X•X•X•X•X•X•

Grounding conductors

Inductance equations for copper conductors

- Round copper wire L = 2ℓ { In(4ℓ/d) 1} x 10⁻ μH
- Rectangular copper strapping L = 2ℓ { In[2ℓ/(b +c)] + ½}x
- Round copper tubing $L = 2\ell \{ \ln(2\ell/r) \frac{3}{4} \} \times 10^{-7} \mu H$
 - D(pH)

 - d (diameter in meters)
 - b & c (width and thickness resp. in meters)
 - r (radius in meters)

Calculated inductances L (µH)

Conductor Inductance	Cross-sect. Area
# 10 copper wire: 1.27 µH/m	0.0104 inch ²
# 6 copper wire: 1.18 µH/m	0.021 inch ²
• 1/2" copper water pipe: 0.91 µH/m	0.307 inch ²
• 2" x 0.011" copper strap: 0.84 µH/m	0.022 inch ²
• 3/4" inch copper water pipe: 0,70 µH/m	0.600 inch ²


Surface area matters at RF frequencies


•	Conductor	Circumference	Width
•	# 10 copper wire.	0.32 inches	8.12 mm
X	# 6 copper wire:	0.51 inches	13.00 mm
•	1/2 " copper water pipe:	1.96 inches	49.80 mm
•	2 x 0.011 inch copper strap:	4.00 inches	101.60 mm
•	3/4 "copper water pipe:	2.36 inches	59.90 mm

Surge currents on conductors


- Ohm's law for inductances
- $V = |X_L| = |2\pi f L| = |2\pi (1/T) L$
- Suppose you have a 10 meter (32') copper conductor:
- What is the voltage difference between the ends with a surge current of 200 amps with a rise time of 2 μs.
- + #6 Copper wire: ΔV = 754 volts
- 2" Copper strap: ΔV = 528 volts


- Ohm's Law for Resistance
- ΔV = IR = 2.6 volts, much smaller than the induced voltage...essentially negligible






















(9) 7/8 coax = 24.75" circumference (3) 1/2 coax = 4.75" circumference Total Circumference = 29.50"







Lightning suppressors







Ron Block KB2UYT in QST

Coaxial In-Line Arrestor



IS-B50LU-C0 | Broadband dc Blocked Protector

The IS-B50 is a dc blocked 50 Ohm bulkhead mounted protector and should be connected directly to a bulkhead or a master ground bar

Availability:

In stock

Request Quote

TECHNICAL SPECIFICATIONS

Customer Print

Freq. (MHz): 1.5 - 400

RF Power (Watts): 125 - 2000 Watts

Application: HF test

Unit Imp. (Ohms): 50 Q

Throughput Energy (µJ): ≤ 10000.0000 µJ

Throughput Voltage (Volts): ≤ 900 Vpk

Weatherized: No

Protected Side Connector: UHF Female

Surge Side Connector: UHF Female


Insertion Loss (dB): 0.1

Mounting: Bulkhead

Turn On Voltage (Volts): +/- 600 V

VSWR: 1.2:1








* Common ground point * Fuse or circuit breaker

* Safety interlock on high voltage supplies


* Everyone in your house should know how to shut off the power









Lightning strike ground saturation before strike @ t = -




Lightning strike ground saturation immediately after incident @ t = +




Lightning strike ground saturation immediately after incident @ t = 2+




Lightning strike ground saturation immediately after incident @ t = 3+





Lightning strike ground saturation immediately after incident @ t = 4+





Lightning strike ground saturation immediately after incident @ t = 5+













- #2 AWG for other than Florida lightning
- #1/0 AWG for Florida lightning
- Building ground rings bonded together minimum #1/0 AWG (Florida)
- Ends of the conductor exothermic weld or listed irreversible high-compression connector

Feed Lines and Grounding


- Coax lines -- in underground conduit rather than going overhead.
- In-line surge protectors on coax and shunt protectors on rotator cable at the base of the tower.
- Ground rods at each tower leg and additional rods spaced at twice their length and all tied together
- Perimeter ground and the AC service ground at entrance panel (service ground).
- Single Point Ground at entry point to shack tied to perimeter ground.
- Feed lines: Ground coax shields at base of tower











Unprotected Structure





























POTENTIAL PROBE POSITIONS


Ground system measuring




Ground stakes











RECOMMENDED DEPTH


MINIMUM DEPTH




BURIED GROUNDING ELECTRODE CONDUCTORS 76 cm (2.5 ft) 2.4 m maximum (8 ft)





Incorrect Spacing



Correct Spacing









Star Grounding Pattern ~ 5 ohms









Perimeter Grounding Pattern





Examples from HARGER Lightning Protection Grounding Equipment Catalog





Examples from HARGER Lightning Protection Grounding Equipment Catalog





Reduce metal corrosion in soil type

Gravelly soils -- least aggressive

Sandy soils


Silty soils - loam


Clays


Peat and other organic soils


Made up soils containing cinders - most aggressive


































































Lightning Protection


- Whole house surge protectors at the entrance panel.
- Surge protectors at appliance locations (Radio Room)
- Single point ground connected to service ground at entrance panel routed outside of the residence.
- Surge protectors on all antenna lead-ins.
- Towers grounded and connected to the single point ground.
- Coax shields grounded to tower legs as low as possible.


















MYTH: Cone Of Protection


 Lightning won't strike within a cone within 45° of a tall isolated object, since it will attract lightning that close



REALITY: Lightning Can Easily Strike Inside The So-Called "Cone Of Protection"



REALITY (continued): Even If Lightning Strikes The Object, You're Still In Danger As It Dissipates Along The Ground Or Side Flash




Myth: Average homeowners lightning insurance claim is over \$10,000.

Year	Number of Claims	Value of Claims (\$ millions)	Average Cost Per Claim
2004	278,000	\$735.5	\$2,646
2005	265,700	819.6	3,084
2006	256,000	882.2	3,446
2007	177,100	942.4	5,321
2008	246,200	1,065.5	4,329
2009	185,789	798.1	4,296
2010	213,278	1,033.5	4,846
2011	186,307	952.5	5,112
2012	151,000	969.0	6,400
2013	114,740	673.5	5,869
% change, 2004-2013	-58.7%	-8.4%	121.8%
% change, 2012-2013	-24.0%	-30.5%	-8.3%


Source: Insurance Information Institute, State Farm®.













































- What is not lightning protection?
 - Early steamer Emission EME
 - **♦**Radioactive
 - **♦ Pulse Voltage**
 - Sparking Controlled Leader Trigger (CLT)
 - Lightning Elimination
 - **◆Dissipation Array System (DAS)**
 - Charge Transfer System (CTS)
 - Not allowed by
 - DOD
 - E

 - NEPA





SEAWORLD ORLANDO LIGHTNING INCIDENT

FAILURE OF THE SECOND GENERATION EARLY STREAMER EMISSION LIGHTNING 1100





Z.A. Hartono s. i Robiah September 2012 Foult columbus diese pro







































When turning off the radio: Please follow the "rules of disagagement"

- Physical unplug all cables from the single point ground to ham equipment
- Ground all antennas Best outside the station building
- Ground everything which enter the shack
- Unplug AC power at wall outlets

If one forgets and you have not followed the "rules of disagagement", a near-by strike might migrate and bypass your lightning protection system



Not an expert in grounding and/or in lightning protection

Have some personal experience with lightning, lightning damage and lightning protection

Never worked professionally in any capacity in lightning or protection from lightning

Suggested lightning protection procedures may reduce total damage



Or Not



...and unpredictable!



