



ludwich66 /
Quansheng_UV-K5_Wiki

[Code](#)[Issues 1](#)[Pull requests 1](#)[Discussions](#)[Actions](#)



Schematic_Power_USB

[Jump to bottom](#)

ludwich66 edited this page on Oct 3, 2023 · [9 revisions](#)

Unaudited Please Verify

UVK5_reversing-USB-Charge.pdf



Numbers see https://github.com/ludwich66/Quansheng_UV-K5_Firmware/wiki/Parts---Teile

▶ Pages 58

Developer community

- [Developer Links / Info Channels](#)

Home

- [Brands](#)
 - [Specials](#)
- [Media & Hacks & Links](#)
- [Block-Diagram](#)
- [DP32G030 Assignment](#)
- [EEPROM-Map](#)
- [Manuals](#)
 - [Manual_Appendix_CTCSS-Frequencies](#)
 - [Manual_Appendix_DCS-Codes](#)
 - [Manual_Appendix_Voice-Inversion-Frequencies](#)
- [Approvals & Certificates](#)

Hardware

- [Antenna](#)
- [Battery](#)
- [KiCad Symbol for UV-K5 Family](#)
- [PCB_Overview](#)
- [Schematics](#)
 - [Complete Schematic PCB 1.4 V0.9](#)
 - [Complete Schematic PCB 1.4 BOM](#)
 - [Interactive Bill-of-Material PCB 1.4 \(iBOM\)](#)
 - [Hardware Details](#)
 - [Schematic_Charger KiCad](#)

- [OLD Schematic's from Gabi](#)
- [OLD Schematic_RX](#)
- [OLD Schematic_TX](#)
- [OLD Schematic_Power_USB](#)
- [Schematic_Akku](#)
- [Programming-Cable, Handset](#)
- [Charging-Cable](#)
- [OLD Parts](#)
 - [OLD Part Details](#)
- [Measurements](#)
- [Hardware_Mods](#)
 - [Hardware_Mods_3D](#)
 - [Hardware_Mods_27-Mhz](#)
- [Accesories](#)
 - [Programming-Cable](#)
 - [Car-Charge Battery-Eliminator](#)
 - [USB-C Battery-Pack](#)
 - [Quansheng-Dock-Cable](#)

Software

- [Configuration-and-Update](#)
 - [CHIRP](#)
 - [K5-Prog-CLI](#)
 - [K5-Prog-Win](#)
 - [Official Configtool
\(Portable Radio CPS \)](#)
- [Official Firmware](#)
- [Community Firmwares](#)
- [UV-K5 Fonttable ToDo](#)
- [UV-K5 Custom BL for Multi FW](#)

Clone this wiki locally

https://github.com/ludwich66/Quansheng_UV-K5_Wiki.wiki.git

