

nikantgr / **egzumer-uv-k5-firmware-custom-nikant**

[Code](#) [Pull requests](#) [Actions](#) [Projects](#) [Security](#) [Insights](#)

[Releases](#) [Tags](#) [Find a release](#)

2 days ago

nikant nk0.0.666 8fdb479 Compare ▾

nk0.0.666

Latest

YouTube video:  <https://youtu.be/MLPoWIbCOSU>

⚠️ Warning

⚠️ ! 💀 EXPERIMENTAL PLAYGROUND

Your warranty is now void. I am not responsible for bricked devices, dead radios, thermonuclear war. YOU are choosing to make these modifications, and if you point the finger at me for messing up your device, I will laugh at you.

If you want to have a more stable FW, I advise you to look at other options.

💀 ! ⚠️

LICENSE: Thanks to closed source firmwares (like IJVs) the modifications made by me in the codebase are now licensed under GNU GPL v3 from now on.

This means anyone who distributes a changed version of this code containing code added by me must:

- Share the source code for their changes: This allows others to see what was modified and potentially build upon your work.
- Make the source code available upon request: Even if someone

receives the original code, they can still request the source code for any modifications you made.

(Chromium based browsers only)

FLASH WITH A BROWSER

FLASH WITH A BROWSER - negative LCD

v.nk0.0.666

- WELCOME TO HELL

- Hellschreiber mode in messenger.

Messenger now has two modes: MORSE and HELL

You can send Hellschreiber tones in Feld Hell mode and 900 Hz

To enter press F + M

To change mode press *

Write your text and press M

T9 keyboard is:

[0 1 . , ?] [A B C 2 @] [D E F 3 -]

[G H I 4 !] [J K L 5 *] [M N O 6 :]

[P Q R S 7] [T U V 8 /] [W X Y Z 9]

Tested with "IZ8BLY Hellschreiber for windows"

<https://antoninoporcino.xoom.it/Hell/>

Each message is transmitted twice

- added switch Wide/Narrow in selection of sidekeys or long press M

- bugfix in Morse Messenger when keypad is locked

- DTMF calling is OFF. We need the space

 Important

Frequently Asked Questions/Requests/Facts:

- Your firmware does not have XYZ feature!
- It does not work in my UV-K5, PC, my CHIRP!
- Can you make the firmware do BLAH BLAH and roll over?
- Firmware ZYX8OAA is better than yours!
- IJV

Answers: I DO NOT CARE!

v.nk0.0.5

- bugfix in FM radio when keypad is locked

- bitmaps a bit smaller to save space

- cosmetic font changes

v.nk0.0.4

- "missed call" indicator for missed RX, for up or down VFO position

- added "W" symbol for Wide on screen

v.nk0.0.3

- compiled with ENABLE_REDUCED_POWER

v.nk0.0.2

- CAN YOU MORSE ?

- MORSE CODE tones TX added in messenger style interface.

To enter press F + M

Write your text and press M

T9 keyboard in Morse mode is:

[0 1 . , ?]	[A B C 2 @]	[D E F 3]
[G H I 4]	[J K L 5]	[M N O 6]
[P Q R S 7]	[T U V 8]	[W X Y Z 9]

- **PASSWORD** set in menu: 6 digits

- lower timings in Dual Watch mode (this is under test!)

- SQUELCH can now be TEMPORARILY changed by pressing F +  (Up or Down arrows)

- FM radio is now minimal taken from kamilsss655 firmware with my addition in order to be able to input a frequency. No memories though..

v.nk0.0.1

- frequencies are now 18MHz ~ 660MHz and 840MHz ~ 1300MHz as per BK4819 specs <https://www.alldatasheet.com/datasheet-pdf/pdf/1756567/BEKEN/BK4819.html>

- NOAA frequencies replaced with 10 first PMR frequencies

- added vertical line to separate menus from submenus

- Makefile changes: ENABLE_SHOW_CHARGE_LEVEL

- modification of ENABLE_BOOT_BEEPS (if Beeps enabled in Menu). Boot beep changed to a sound similar to Baofeng UV-5R

- addition of ENABLE_INVERSE_DISPLAY : Well that.. (negative LCD)

- changes to POWER_ON_DISPLAY_MODE_FULL_SCREEN

- UNLOCK ALL frequencies to the hidden F LOCK menu now 3 times to activate

- all small fonts are bold for better readability and because I am old 😊 (and to save some space in firmware)

▼ Assets 4

 [firmware.EGZUMER-NIKANT.666.packed.bin](#)

57.4 KB

9 hours ago

 [firmware.EGZUMER-NIKANT.negativeLCD.666.packed.bin](#)

57.4 KB

9 hours ago

 [Source code \(zip\)](#)

Mar 27

 [Source code \(tar.gz\)](#)

Mar 27



1 person reacted

Apr 27

 nikant

 nk0.0.5

 8fdb479 

Compare ▾

nk0.0.5

YouTube video:  <https://youtu.be/IJBkC0Dh5mQ>

⚠ Warning

⚠ ! 💀 EXPERIMENTAL PLAYGROUND

Your warranty is now void. I am not responsible for bricked devices, dead radios, thermonuclear war. YOU are choosing to make these modifications, and if you point the finger at me for messing up your device, I will laugh at you.

If you want to have a more stable FW, I advise you to look at other options.



LICENSE: Thanks to closed source firmwares (like IJVs) the

modifications made by me in the codebase are now licensed under GNU GPL v3 from now on.

This means anyone who distributes a changed version of this code containing code added by me must:

- Share the source code for their changes:** This allows others to see what was modified and potentially build upon your work.
- Make the source code available upon request:** Even if someone receives the original code, they can still request the source code for any modifications you made.

(Chromium based browsers only)

FLASH WITH A BROWSER

FLASH WITH A BROWSER - negative LCD

v.nk0.0.5

- bugfix in FM radio when keypad is locked
- bitmaps a bit smaller to save space
- cosmetic font changes

v.nk0.0.4

- "missed call" indicator for missed RX, for up or down VFO position
- added "W" symbol for Wide on screen

v.nk0.0.3

- compiled with **ENABLE_REDUCED_POWER**
-

v.nk0.0.2

- CAN YOU MORSE ?

- MORSE CODE tones TX added in messenger style interface.

To enter press F + M

Write your text and press M

T9 keyboard in Morse mode is:

[0 1 . , ?]	[A B C 2 @]	[D E F 3]
[G H I 4]	[J K L 5]	[M N O 6]
[P Q R S 7]	[T U V 8]	[W X Y Z 9]

- PASSWORD set in menu: 6 digits

- lower timings in Dual Watch mode (this is under test!)

- SQUELCH can now be TEMPORARILY changed by pressing F + ⌂ (Up or Down arrows)

- FM radio is now minimal taken from kamilss655 firmware with my addition in order to be able to input a frequency. No memories though..
-

v.nk0.0.1

- frequencies are now 18MHz ~ 660MHz and 840MHz ~ 1300MHz as per BK4819 specs <https://www.alldatasheet.com/datasheet-pdf/pdf/1756567/BEKEN/BK4819.html>

- NOAA frequencies replaced with 10 first PMR frequencies

- added vertical line to separate menus from submenus

- Makefile changes: **ENABLE_SHOW_CHARGE_LEVEL**
- modification of **ENABLE_BOOT_BEEPS** (if Beeps enabled in Menu). Boot beep changed to a sound similar to Baofeng UV-5R
- addition of **ENABLE_INVERSE_DISPLAY** : Well that.. (negative LCD)
- changes to **POWER_ON_DISPLAY_MODE_FULL_SCREEN**
- **UNLOCK ALL frequencies to the hidden F LOCK menu now 3 times to activate**
- all small fonts are bold for better readability and because I am old 😊 (and to save some space in firmware)

► Assets 6



1 person reacted

Apr 16



nk0.0.4

-o 8fdb479

Compare ▾

nk0.0.4

YouTube video: <https://youtu.be/IJBkC0Dh5mQ>

⚠ Warning

⚠ ! 💀 EXPERIMENTAL PLAYGROUND

Your warranty is now void. I am not responsible for bricked devices, dead radios, thermonuclear war. YOU are choosing to make these modifications, and if you point the finger at me for messing up your device, I will laugh at you.

If you want to have a more stable FW, I advise you to look at other options.



LICENSE: Thanks to closed source firmwares (like IJVs) the

modifications made by me in the codebase are now licensed under GNU GPL v3 from now on.

This means anyone who distributes a changed version of this code containing code added by me must:

- Share the source code for their changes:** This allows others to see what was modified and potentially build upon your work.
- Make the source code available upon request:** Even if someone receives the original code, they can still request the source code for any modifications you made.

(Chromium based browsers only)

FLASH WITH A BROWSER

FLASH WITH A BROWSER - negative LCD

v.nk0.0.4

- "missed call" indicator for missed RX, for up or down VFO position**
- added "W" symbol for Wide on screen**

v.nk0.0.3

- compiled with ENABLE_REDUCED_POWER**

v.nk0.0.2

- CAN YOU MORSE ?**

- MORSE CODE tones TX added in messenger style interface.

To enter press F + M

Write your text and press M

T9 keyboard in Morse mode is:

[0 1 . , ?]	[A B C 2 @]	[D E F 3]
[G H I 4]	[J K L 5]	[M N O 6]
[P Q R S 7]	[T U V 8]	[W X Y Z 9]

- **PASSWORD** set in menu: 6 digits

- lower timings in Dual Watch mode (this is under test!)

- SQUELCH can now be TEMPORARILY changed by pressing F +  (Up or Down arrows)

- FM radio is now minimal taken from kamilsss655 firmware with my addition in order to be able to input a frequency. No memories though..

v.nk0.0.1

- frequencies are now 18MHz ~ 660MHz and 840MHz ~ 1300MHz as per BK4819 specs <https://www.alldatasheet.com/datasheet-pdf/pdf/1756567/BEKEN/BK4819.html>

- NOAA frequencies replaced with 10 first PMR frequencies

- added vertical line to separate menus from submenus

- Makefile changes: ENABLE_SHOW_CHARGE_LEVEL

- modification of ENABLE_BOOT_BEEPS (if Beeps enabled in Menu). Boot beep changed to a sound similar to Baofeng UV-5R

- addition of ENABLE_INVERSE_DISPLAY : Well that.. (negative LCD)

- changes to POWER_ON_DISPLAY_MODE_FULL_SCREEN

- UNLOCK ALL frequencies to the hidden F LOCK menu now 3 times to activate

- all small fonts are bold for better readability and because I am old 😊 (and to save some space in firmware)

► Assets 6



Apr 12

nikant nk0.0.3 8fdb479 Compare ▾

nk0.0.03

YouTube video: <https://youtu.be/IJBkC0Dh5mQ>

Warning

! EXPERIMENTAL PLAYGROUND

Your warranty is now void. I am not responsible for bricked devices, dead radios, thermonuclear war. YOU are choosing to make these modifications, and if you point the finger at me for messing up your device, I will laugh at you.

If you want to have a more stable FW, I advise you to look at other options.



LICENSE: Thanks to closed source firmwares (like IJVs) the modifications made by me in the codebase are now licensed under GNU GPL v3 from now on.

This means anyone who distributes a changed version of this code containing code added by me must:

- Share the source code for their changes: This allows others to see what was modified and potentially build upon your work.

- Make the source code available upon request: Even if someone receives the original code, they can still request the source code for any modifications you made.
-

(Chromium based browsers only)

FLASH WITH A BROWSER

FLASH WITH A BROWSER - negative LCD

v.nk0.0.3

- compiled with **ENABLE_REDUCE_LOW_POWER**

v.nk0.0.2

- CAN YOU MORSE ?

- MORSE CODE tones TX added in messenger style interface.

To enter press F + M

Write your text and press M

T9 keyboard in Morse mode is:

[0 1 . , ?] [A B C 2 @] [D E F 3]

[G H I 4] [J K L 5] [M N O 6]

[P Q R S 7] [T U V 8] [W X Y Z 9]

- PASSWORD set in menu: 6 digits

- lower timings in Dual Watch mode (this is under test!)

- SQUELCH can now be TEMPORARILY changed by pressing F + ⌂ (Up or Down

arrows)

- FM radio is now minimal taken from kamilsss655 firmware with my addition in order to be able to input a frequency. No memories though..
-

v.nk0.0.1

- frequencies are now 18MHz ~ 660MHz and 840MHz ~ 1300MHz as per BK4819 specs <https://www.alldatasheet.com/datasheet-pdf/pdf/1756567/BEKEN/BK4819.html>
 - NOAA frequencies replaced with 10 first PMR frequencies
 - added vertical line to separate menus from submenus
 - Makefile changes: ENABLE_SHOW_CHARGE_LEVEL
 - modification of ENABLE_BOOT_BEEPS (if Beeps enabled in Menu). Boot beep changed to a sound similar to Baofeng UV-5R
 - addition of ENABLE_INVERSE_DISPLAY : Well that.. (negative LCD)
 - changes to POWER_ON_DISPLAY_MODE_FULL_SCREEN
 - UNLOCK ALL frequencies to the hidden F LOCK menu now 3 times to activate
 - all small fonts are bold for better readability and because I am old 😊 (and to save some space in firmware)
-

► Assets 6



Apr 7

nikantgr nk0.0.2 8fdb479 Compare ▾

nk0.0.2

YouTube video:  <https://youtu.be/IJBkC0Dh5mQ>

 Warning

 !  EXPERIMENTAL PLAYGROUND

Your warranty is now void. I am not responsible for bricked devices, dead radios, thermonuclear war. YOU are choosing to make these modifications, and if you point the finger at me for messing up your device, I will laugh at you.

If you want to have a more stable FW, I advise you to look at other options.



LICENSE: Thanks to closed source firmwares (like IJVs) the modifications made by me in the codebase are now licensed under GNU GPL v3 from now on.

This means anyone who distributes a changed version of this code containing code added by me must:

- Share the source code for their changes: This allows others to see what was modified and potentially build upon your work.
- Make the source code available upon request: Even if someone receives the original code, they can still request the source code for any modifications you made.

(Chromium based browsers only)

 **FLASH WITH A BROWSER** 

 **FLASH WITH A BROWSER**  - negative
LCD

v.nk0.0.2

- CAN YOU MORSE ?

- MORSE CODE tones TX added in messenger style interface.

To enter press F + M

Write your text and press M

T9 keyboard in Morse mode is:

[0 1 . , ?]	[A B C 2 @]	[D E F 3]
[G H I 4]	[J K L 5]	[M N O 6]
[P Q R S 7]	[T U V 8]	[W X Y Z 9]

- PASSWORD set in menu: 6 digits

- lower timings in Dual Watch mode (this is under test!)
- SQUELCH can now be TEMPORARILY changed by pressing F +  (Up or Down arrows)
- FM radio is now minimal taken from kamilsss655 firmware with my addition in order to be able to input a frequency. No memories though..

v.nk0.0.1

- frequencies are now 18MHz ~ 660MHz and 840MHz ~ 1300MHz as per BK4819 specs <https://www.alldatasheet.com/datasheet-pdf/pdf/1756567/BEKEN/BK4819.html>
- NOAA frequencies replaced with 10 first PMR frequencies
- added vertical line to separate menus from submenus
- Makefile changes: ENABLE_SHOW_CHARGE_LEVEL
- modification of ENABLE_BOOT_BEEPS (if Beeps enabled in Menu). Boot beep changed to a sound similar to Baofeng UV-5R
- addition of ENABLE_INVERSE_DISPLAY : Well that.. (negative LCD)
- changes to POWER_ON_DISPLAY_MODE_FULL_SCREEN

- **UNLOCK ALL frequencies to the hidden F LOCK menu now 3 times to activate**
 - **all small fonts are bold for better readability and because I am old 😊 (and to save some space in firmware)**
-

► **Assets** 6

