

Accessory

BACKREST BRACKET P/N 08R71-MJF-A00ZP Application

CTX700N/ND (Page 1)

CTX700/D (Page 2)


Publication No.

MII 14476


Issue Date

Revised August 2014

PARTS LIST



No.	Description	Qty
(1)	Right backrest stay	1
(2)	Left backrest stay	1
(3)	8 mm flange bolt (long)	4
(4)	Collar (thick)	2
(5)	Collar (thin)	2
(6)	8 mm flange bolt (short)	4
(7)	8 mm flange bolt (medium)	4
(8)	8 mm flange cap nut	2
(9)	Installation Instruction URL	1
(10)	8 mm socket bolt (Not used.)	4



No.	Description	Qty		
(1)	Right inner support stay	1		
(2)	Left inner support stay	1		
(3)	8 mm flange bolt	6		
(4)	Cushion	2		
(5)	Installation Instruction URL	1		

TOOLS REQUIRED

Socket (12 mm)
Ratchet
Box-end wrench (12 mm)
Torque wrench

TORQUE CHART


Tighten all screws, bolts, and nuts to their specified torque values. Refer to the Service Manual for the torque values of the removed parts.

Item	N∙m	kgf∙m	lbf·ft
8 mm flange bolt and cap nut	27	2.8	20
8 mm socket bolt	22	2.2	16

INSTALLATION (CTX700N/ND)

NOTE:


- Take care not to damage the painted surfaces of the motorcycle.
- Illustrations show CTX700N type, other type is similar.
- 1. Refer to the Installation Instructions for the separately sold inner support, install the inner support to the motorcycle.
- 2. Loosely install the backrest bracket as shown.
 - Repeat on the right side.



INSTALLATION (CTX700/D)

NOTE:

- Take care not to damage the painted surfaces of the motorcycle.
- 1. Refer to the Service Manual for the motorcycle, remove the rear grips.
 - Repeat on the right side.



- 2. Loosely install the backrest bracket as shown.
 - Repeat on the right side.

