



GPS board to sync date, time, latitude and longitude with OE5JFL controller.



Connect the 2x16 LCD display with the supplied 6pin flatcables. On the GPS board left pin from LEFT connector to the left pin from LEFT connector on the LCD. And so on for all 12 wires. Straight cables.



Connections GPS

RED = +5V,
BLACK = GND,
BLUE = TX data (connect to 'GPS data in' on board above).

