


G7 EXPLODED VIEW



REV.00 (ISSUED Apr. 01, 2005)

| NO | ITEM NO. | DESCRIPTION | Q'TY | REV. | REMARK |
|------|------------|---------------------------------------|------|------|------------------|
| 1 | G7-018 | POP LABEL | 1 | | |
| 2 | G7-006 | LCD WINDOW | 1 | | |
| 3 | GXT300-015 | DOUBLE SIDE TAPE for WINDOW | 1 | | |
| 4 | G7-001 | FRONT COVER | 1 | | |
| 5 | GXT300-011 | LCD BRACKET | 1 | | |
| 6 | GXT300-009 | KEY PAD | 1 | | |
| 7 | GXT300-016 | ZEBRA | 1 | | |
| 8 | GXT300-007 | BACK LIGHT LENS | 1 | | |
| 9 | G5-016 | DOUBLE SIDE TAPE for REFLECTIVE SHEET | 1 | | |
| 10 | G225-009 | REFLECTIVE SHEET | 1 | | |
| 11 | G223-018 | METAL DOME for PTT BUTTON | 1 | | |
| 12 | GXT300-010 | PTT BUTTON | 1 | | |
| 13 | GXT300-012 | D-SPRING | 1 | | |
| 14 | GXT300-004 | VOLUME KNOB | 1 | | |
| 15 | G7-008 | ANTENNA HOUSING | 1 | | |
| 16 | | ANTENNA COIL | 1 | | |
| 17 | | SCREW | 5 | | (PH) 2.6X8 Black |
| 18 | GXT300-005 | BATTERY HOLDER | 1 | | |
| 19 | 7N-016 | TERMINAL-E | 1 | | |
| 20 | GXT300-002 | BACK COVER | 1 | | |
| 21 | G7-017 | PRODUCTION LABEL | 1 | | |
| 22 | | E-RING | 1 | | |
| 23 | GXT300-019 | CLIP for BELT | 1 | | |
| 24 | GXT300-021 | SPRING for CLIP | 1 | | |
| 25 | GXT300-022 | PIN for CLIP | 1 | | |
| 26 | GXT300-020 | HINGE | 1 | | |
| 27 | G223-016 | CHARGE TERMINAL | 2 | | |
| 28 | GXT300-003 | BATTERY COVER | 1 | | |
| 29 | GXT300-013 | TERMINAL-A | 1 | | |
| 30 | 7N-013 | TERMINAL-B | 1 | | |
| 31 | 7N-015 | TERMINAL-D | 1 | | |
| 32 | GXT300-014 | TERMINAL-C | 1 | | |
| 33 | | SHIELD PLATE | 1 | | |
| 34 | G223-017 | VCO CAN | 1 | | |
| 35 | | FELT for SPEAKER | 1 | | |
| 36 | RT444-009 | JACK CAP | 1 | | |
| LCD | | LCD | 1 | | |
| PCB | | PCB | 1 | | |
| MIC | | MIC | 1 | | |
| SPK. | | SPEAKER | 1 | | |